





www.furuno.com

FURUNO VOYAGER, next-generation bridge system, has been designed using our decades of expertise in sensor devices, network integration and software development. FURUNO VOYAGER bridge system offers multifunction workstations with seamless display of Radar/Chart Radar, ECDIS, Conning and Alert Management System data. FURUNO VOYAGER bridge systems have been developed with a completely new and intuitive user interface and in strict accordance with the most up-to-date safety and navigation standards in mind.

FURUNO VOYAGER, the next-generation bridge system

Total network sensor integration delivers enhanced situational awareness to the mariner. An uncomplicated display presentation simplifies and streamlines navigational tasks. Common responsibilities such as route planning, navigation status monitoring, log-keeping, alarm awareness and day-to-day chart management are made easy through common workstation layout and redundancy of display and control. Watchstanders will enjoy reduced workload and significant freedom to move about the bridge, with all necessary information available in a variety of displays and locations.




Track Control System permits automatic steering along the set route

FURUNO VOYAGER features Track Control System through integration of ECDIS and autopilot. This enables the vessel to keep on the plotted route automatically with minimum intervention from the navigator. This has been achieved through:

- Flexible steering control
- route planning on ECDIS
- enhanced position reliability through multi-tiered data validation process

The operator is alerted to navigational warnings and potential dangers before the vessel is at risk.



FURUNO's new user interface delivers straightforward, task-based operation

RCU-025



RCU-024



- A Common key assignment is arranged for the common tasks, such as EBL, VRM controls, on the control units of ECDIS and Radar/Chart Radar
- B Operation scheme close to a PC with the use of the trackball.
 - Trackball: to move the cursor and select an object
 - Left-click: to perform/confirm the action related to the selected object
 - **Right-click**: to display contextual menu while cursor is on the display area. and to cancel action done on the selected object

Scrollwheel: to select menu items

Task-based user interface realized by combination of Status bar and InstantAccess bar[™] providing quick access to the needed tasks/functions

FURUNO VOYAGER user interface includes carefully organized operational tools designed to make navigational tasks simple and easy. The "Status Bar" at the top of the screen clearly indicates operating mode and status and offers direct single-click control of the navigator's principle tasks. The Instant Access bar™ at the left of the screen provides direct control of the features and attributes of the on-screen presentation. These on-screen tools deliver straightforward, task-based operation with all multi-function display information in view at all times. The operator can quickly perform navigational tasks without having to enter intricate menus, thus losing situational awareness.

Contextual menu

Contextual menu contains all the available actions related to the position of the cursor, hence providing quick access to tasks required.



ECDIS

RADAR



Multifunction display (MFD) capability

FURUNO Voyager offers workstations that combine flexibility and redundancy. Users may easily select ECDIS, Chart Radar, Conning display or Alert Management System at any multi-function display. Navigators will enjoy reduced workload and significant freedom to move about the bridge, with all necessary information available in a variety of displays and locations.

> Operator-preset conning display orientation can be summoned upon clicking on the dedicated buttons on the status bar.

Conning display

In the Conning display mode, sensor information and real-time navigation data are presented to navigators in a thoughtfully designed display presentation.

Information to be shown in the conning display:

- Heading Pitch and Roll Rudder angles Rate of Turn
- Position fix
 Speed (bow speed, longitudinal speed and stern speed)
- Propeller pitch
 Wind speed and direction (both true and relative)
- Thrusters pitch Alert list BNWAS indication Date and time, etc.





Alert Management System

Alert Management System presents and prioritizes alert status and information. The well designed display layout gives operators the ability to quickly identify alert situations, and the actions required to rectify the cause of the alert.

The Alert management System complies with MSC.302(87) Performance Standards for Bridge Alert Management.

ACTIVE ALERT



List of alerts currently active can be viewed.

ALERT LOG

we =:	TRAINE ADDING	1997 - Derenand	-	0	
Principal Scoren i		laton Referenci	Log Search - 💼		There are a
-		THE Page 1	- 1991) - 1991		
from:	c destas -	Balant	Owned free lates	10.144-010	Antalwa Terena ACC
	1011 Fallys in Ballattin in Press Fally		TT THE R AND TOTAL	11/10/10 Kee 2711	
Rent .	000 No. 1 5-5 Control Proves Ral	MOAR	11110-00-00-00111	IT SERVICES	TTESE STAND VOLT
April	CO. No.2 STL Control Provel Nation		11/14/07 Mile 3011	through the sold	TO SHEEK MAN VIET
Signal 1	004 No. 9 Krig Cantool Reason Fail		11139-03 May 3811	11 10 11 404 32 1	21108254442071
April	000 No.1 America Not Neek Lock?	MAAR	11.104 (3.Mec 2011)	TT SHAR MAN 3211	1106034662011
warme	059 NJ.2 Accelor full Hell Look?	Highes I	11:28-03 May 2015	TOTAL OF MAN 1211	TINE STATE
w				It start which be it	TO DRIVE MAN JUST
Winnet	US2 No.3 Actume full level Look/		TTTR CS May JULY	11:39 (21 May 231)	11110 01 May 2011
Warning	ISSE Internet All CPU hat				
Wenne	1941 Descalary D3 Manage R040 Fall	MOAR	11115-03-Mee.1011	11.59-03 Mei 2011	TTNE SKAME 2011
	043 Dimensional Feb Auto Rudder Curput Fel		11:59 GT May 2011	11:59 (3) Year 301	11158 Bill Mile 2017
Catter	D43 Emergence (3) Sans (2mergen travel tak	-ANCAR	TTSESTMETET	TOTAL NUMBER OF TAXABLE	TISH SHAR STT
Genter	AND DISCOURSE (IN MUN Consecution field				1110000Me 7011
Dellar	O45 Internet (711 Feed Salk Feb	101617	1111020 Mile 3011	11 10 11 May 30 1	1138 00 Mar 2011
	004 Investorial / Avertail ful		C TOPOT Merch1011		
Carlor	G47 Elizopeta 03.3 Section And	1:361	11.38-02 Max 3011	11 10 10 May 2011	11104 III Mas 2017
	DIE Immersion 11 1 faits time from		11134-03 Mile 3011	11:10-10 May 1211	TTTS#EXAMPLEMENT
Deaters	049 Investor 12.2 Serve Love Tree		11:38-03 Mile 3811	17:59 33 May 2011	115823 May 2014
			10.1643.644.3011	11:10 88 Mar 2011	11258-00 May 2011
	615 Ithesess (SUAmare Inst		11138-03 Mile 2015	11 THE READ AND IN T	

Alert history can be viewed in chronological order. The source of alerts, and the date and time each alert was raised, acknowledged and rectified are shown.

- 1 Listed alerts can be filtered by priority levels and alert sources.
- 2 All the alerts listed on the displays can be acknowledged by clicking on "ACK All".
- ³ All the audible alerts can be silenced by clicking on "Silence".
- ⁴ The nature of the alert situation selected as well as remedy to rectify the alert situation is presented in the "Decision Support" area.

Some film: Risariation @Companyat	ion Rifferial	Kalman She resident that to complete 5 metric that avoid in By itstalfation surgeneters	Record works of resultions
Alert Ted Att 11: Bream Facultaria Att 21: Sever Facultaria Att 22: Creation Att 23: Sever Facultaria Att 24: Sever Facultaria Att 25: Sever Facultaria	Active Sale Active Acti	toon bearunfon addroomstaaid Alarin mooleagad Alarin anooleagad Alarin anooleagad Alarin anooleagad Alarin anooleagad Alaring nooleagad Alaring nooleagad Varing anooleagad Varing anooleagad anooleagad Varing anooleagad	

By clicking on the **I** in the ACTIVE ALERT page, the list of icons used in the Alert Management System and their descriptions can be shown as a pop-up window.

ALERT LIST

ANA ATTACALAT ALLAS	100 AURITLET	0	11-11-22-11-12-03
5	A letter minimum	No. of Concession, Name	
Hert Source	ANTIA		a contra
Second Co.	Proctorities 2 A marrie 152.001	1 C	E Canton (12-bat)
LICEN IN CONTRACTOR		Paul 110 TW	
4004	and that is not a support		
No.			
The second se			
1014			
32	A Dare Based and backard and		
	A Trans and Anno Anna Anna In		
6.04	O Warnes and the loss		
200	O Weren CO Burgets Officies		
1000	O Warmen B. A Anna Sec & Sec in Condition		
200	Warning U.A Larget Carects		
	Werning Division of Contraction		
Colonal status	Strength 11.6 121 matter light		
100	Name of Contract Contract Street and		
200			
200 C			
1000 C	Warning Hill Academic Sciences		
200			
294	Same Bill Cone		
200	Control 1004 Charles Take		
100 B	And Address of the second state of the second		
100			

List of alerts available for each alert source can be viewed.

- ⁵ The latest active alert is displayed in the ALERT LIST and ALERT LOG pages.
- 6 Keyword search function is available in the ALERT LOG page, and the alert log can be exported to external use.

FURUNO VOYAGER onboard navigation network system


FURUNO VOYAGER integrates the following two separate networks that link all the onboard navigation equipment, including multifunction displays and various sensors: Network for Integration and Interswitch and Network for Sensor Integration.

The navigation system consists of duplicated subsystems so that any loss of navigational functions can be avoided in an event of single point of failure. Since MFD is able to function as radar, ECDIS, conning information display and alert management system, navigation tasks can be performed from any of the interfaced multifunction displays, hence optimizing the system availability. Network for Integration and Interswitch (Gigabit Ethernet) is used to communicate the following data:

- Radar interswitching
- TT and AIS target data
- Harmonization of databases (charts, routes, etc.)

Network for Sensor Integration (combination of 100 Base-TX Ethernet & IEC 61162-1/-2) is used to communicate the following data:

- Sensor data
- Alert information



Sensor adapter

Sensor adapters act as central medium to gather all the sensor data and collectively feed it to all the workstations within the system. Individual cablings in the sensor-to-workstation interface can be greatly reduced. Since arrangement of the sensor adapters can be customized and extended to cover all the sensors within the system, thanks to its component configuration, flexibility can be assured when planning the network structure of the bridge system.





Beware of similar products

All brand and product names are registered trademarks, trademarks or service marks of their respective holders.

FURUNO ELECTRIC CO., LTD. Japan I www.furuno.com FURUNO U.S.A., INC. U.S.A. I www.furunousa.com FURUNO PANAMA S.A. Republic of Panama I www.furuno.com.pa FURUNO (UK) LIMITED U.K. I www.furuno.co.uk FURUNO NORGE A/S Norway I www.furuno.no

FURUNO DANMARK A/S Denmark | www.furuno.dk FURUNO SVERIGE AB Sweden | www.furuno.se FURUNO FINLAND OY Finland | www.furuno.fi FURUNO POLSKA Sp. Z o.o. Poland | www.furuno.pl FURUNO DEUTSCHLAND GmbH Germany | www.furuno.de FURUNO FRANCE S.A.S. France I www.furuno.fr FURUNO ESPAÑA S.A. Spain I www.furuno.es FURUNO ITALIA S.R.L. Italy I www.furuno.it FURUNO HELLAS S.A. Greece I www.furuno.gr FURUNO (CYPRUS) LTDD Cyprus I www.furuno.com.cy

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

FURUNO EURUS LLC Russian Federation | www.furuno.ru FURUNO SHANGHAI CO., LTD. China | www.furuno.com/cn FURUNO CHINA CO., LTD. Hong Kong | www.furuno.com/cn FURUNO KOREA CO., LTD Korea FURUNO SINGAPORE Singapore | www.furuno.sg PT FURUNO ELECTRIC INDONESIA Indonesia | www.furuno.id

> 3-B-18021SS Catalogue No. CA000001228